

PULSAR 700 SERIES

OPERATING & INSTALLATION INSTRUCTIONS SERIES 2200/2600

PLEASE READ CAREFULLY BEFORE INSTALLING

INTRODUCTION

The Series 2200/2600 pressure transducers use molecularly bonded high output strain gauges to provide 100mV output for full range pressure, when used with a 10V d.c. power supply.

Series 2200/2600 high output pressure transducers and transmitters are fitted with an Asic providing various optional (at time of order) voltage outputs, and a 4-20mA current output capable of being used in control and indicating loops without further amplification.

Series 2200/2600 with the CE Mark conform with the essential protection requirements of the EMC Directive 89/33/EEC amended by certified type testing to EN 50082-2 and EN 50081-1.

Series 2200/2600 with the CE0086 mark also complies with the requirements of the Pressure Equipment Regulations 1999 and is classed as a safety accessory and can be used as a safety-related device on Category IV pressure equipment. No other product should be used as "Safety Accessories" as defined by the PED Article 1, Paragraph 2.1.3.

HAZARDOUS PRODUCTS

The Consumer Protection Act of 1987, Section 6 of the Health and Safety at Work Act 1974 and the Control of Substances Hazardous to Health Regulations 1988 require that we advise recipients and users of our products of any potential hazards associated with their storage, handling or use.

The products which our Company supplies may be classified as Electrical, Electro-Mechanical and Electronic equipment.

These products are tested and supplied in accordance with our published specifications or individual special requirements that are agreed in writing at time of order. They are constructed so as not to affect adversely the safety of persons and property when properly installed, maintained and used by qualified personnel, in the applications for which they were designed and manufactured.

Conformity with the requirements of the CE mark only applies when the installation conditions described in these instructions have been met. For units supplied without a cable assembly connection to the transducer must be accomplished using approved cable. See APPROVED CABLE section.

GENERAL

- * Transducer should not be subjected to greater than the maximum allowable pressure (P.S.) / Temperature (T.S) as defined on the transducer label.
- * Transducer should not be subjected to mechanical impact.
- * In the event of fire the end user must ensure that the system pressure is vented to a safe area.

- * The effects of decomposition of unstable fluids should be considered by the user when placing this device in service.
- * The pressure transducer has no means of draining or venting, this must be performed by another component in the end users system.
- * Pressure range must be compatible with the maximum pressure being measured.
- * Pressure media must be compatible with the transducer/transmitter wetted parts listed in these instructions.
- * Liquid must not be allowed to freeze in the pressure port.
- * The gasket must be fitted under the electrical connector.

MECHANICAL INSTALLATION

Mounting: Pressure Transducer is designed to be attached by the coupling thread only. Omni-directional, self supported directly into the pipework. Use a 19mm AF (3/4") spanner on the hexagon provided to apply a maximum torque of 15.8Nm. The Customer must ensure that the pressure seal is suitable for the application.

ELECTRICAL INSTALLATION

All types with the CE Mark include suppression devices providing transient protection to EN 61000-4-2 and EN 61000-4-4. Conformity with the requirements of the CE mark only applies when connection is made with approved cable, see APPROVED CABLE section, and is connected as shown below:-

Millivolt Output Transducers: Four core screened cable should be used with the cable screen connected to the instrumentation earth. The cable screen should not be connected to the transducer body.

High Output Transducers/Transmitters: The screen of the cable must be earthed at the instrumentation end. If an 'Earth Loop' problem is encountered when the body of the unit is earthed by the pipework it is permissible to remove the cable screen from the instrumentation earth.

APPROVED CABLE

Pulsar pressure sensors are supplied with cable comprising 2, 3 or 4 colour-coded cores, enclosed by an aluminised polyester screen where the screen is in intimate contact with a separate drain wire. The outer sheath is chrome PVC and overall diameter is approximately 4 mm.

OPERATION

Having installed the transducers as instructed, they are ready for use. The transducer should not be removed whilst the system is at pressure. Before applying power, check that the correct polarity and excitation levels are being applied. See Table 1 for electrical connections.

CALIBRATION

Transducers are calibrated to the datum requested at time of order; this can be identified by the sixth letter of the identification code as follows:-

A - Absolute datum

G - Gauge datum vented to atmosphere via the electrical connector or cable

LOAD CHARACTERISTICS (4-20mA Current Output)

The total resistive load in the loop (to include all the cable resistance) can be from 'zero to 50 x (supply volts -7) ohms' e.g. with a 24V d.c. supply the permissible load is from zero up to 850 ohms.

OPERATIONAL LIFE:

Limited to 100M cycles to maximum allowable pressure.

WARRANTY

We guarantee this instrument against faulty workmanship and material for a period of two year s from date of delivery. The Company undertake to repair, free of charge, ex-works any instrument found to be defective within the specified period providing the instrument has been used within the specification in accordance with these instructions and has not been misused in any way.

Detailed notice of such defects and satisfactory proof thereof must be given to the Company immediately after the discovery and the goods are to be returned free of charge to the Company, carefully packed and accompanied by a detailed failure report. See "RETURN TO FACTORY".

WETTED PARTS

316 and 17-4 PH stainless steel plus Nickel Braze to BS1845 : NK3/HTN2.

SERVICING

The transducer cannot be repaired locally and if damaged should be returned to ourselves at the address shown below:

Pulsar Process Measurement Limited
Oak House
Bromyard Road
Worcester
Worcestershire
WR2 5HP

RETURN TO FACTORY

PLEASE NOTE: To comply with Health and Safety requirements, the instrument must be clean and safe to handle and accompanied by a formal statement to that effect duly signed by an authorised officer of the Company.

MAINTENANCE

Routine Inspection: Not required except for periodic inspection of the cable and connector to ensure that these are neither damaged nor softened by incompatible liquid.

TABLE 1
CONNECTIONS 2200/2600 SERIES

TYPE NUMBER	CE	CONNECTOR	mV					4-20mA			VOLTAGE			
			IN+	OUT+	OUT-	IN-	EARTH	IN+	IN-	EARTH	IN+	COM	OUT+	EARTH
2200A-A2	YES	MINI DIN STYLE	1	2	3	E								
2200A-D2	YES	CABLE EUROPE	R	Y	BL	G								
2200A-F2	YES	CABLE WEATHER PROOF	R	Y	BL	G								
2200A-22	YES	CABLE USA	R	W	G	BK								
2200X-A3	YES	MINI DIN STYLE						1	2	E	1	2	3	E
2200X-D3	YES	CABLE EUROPE						R	BK	DRAIN	R	BK	W	DRAIN
2200X-F3	YES	CABLE WEATHER PROOF						R	BK	DRAIN	R	BK	W	DRAIN
2200X-23	YES	CABLE USA						R	BK	DRAIN	R	BK	W	DRAIN
2600A-12	YES	8-4P	A	B	C	D								
2600A-C2	YES	10-6P	A	B	C	D								
2600A-G2	YES	LARGE DIN	1	2	3	E								
2600A-M2	YES	MOULDED IMMERSIBLE	R	Y	B	W	DRAIN							
2600AUM2	YES	IMMERSIBLE NO CABLE	R	Y	B	W	G							
2600A-P2	YES	MOULDED IMMERSIBLE	R	Y	B	W	DRAIN							
2600A-32	YES	CONDUIT CABLE	R	W	G	BK								
2600AU32	YES	CONDUIT LEADS	R	W	G	BK								
2600X-13	YES	8-4P						A	B	D	A	C	B	D
2600X-C3	YES	10-6P						A	B	E	A	C	B	E
2600X-G3	YES	LARGE DIN						1	2	E	1	2	3	E
2600X-M3	YES	MOULDED IMMERSIBLE						R	BL	DRAIN	R	W	Y	DRAIN
2600XUM3	YES	IMMERSIBLE NO CABLE						R	BL	G	R	W	Y	GREEN
2600X-P3	YES	MOULDED IMMERSIBLE						R	BL	DRAIN	R	W	Y	DRAIN
2600X-33	YES	CONDUIT CABLE						R	BK	DRAIN	R	BK	W	DRAIN
2600XU33	YES	CONDUIT LEADS						R	BK	G	R	BK	W	G

OUTPUT	SUPPLY VOLTAGE
A 0 to 100mV	10V d.c.
B 4 to 20mA	7 to 35V d.c.
C 1 to 6V	7.5 to 35V d.c.
D 1 to 11V	12.5 to 35V d.c.

OUTPUT	SUPPLY VOLTAGE
H 1 to 5V	6.5 to 35V d.c.
J 0.5 to 5.5V	7 to 35V d.c.
R 0 to 5V	6.5 to 35V d.c.
G 0 to 10V	11.5 to 35V d.c.